Sharkoon

TAURON

ATX PC Case

Manual

Content

1. Features	**3**
2. Package content	**3**
3. The case at a glance	**4**
4. Installation notes	**8**
5. Rebuilding the HDD cages	**9**
6. Installation of a mainboard	**11**
7. Installation of a PSU	**14**
8. Installation of a HDD	**15**
9. Installation of an optical device	**17**
10. Installation of a 3.5" device	**19**
11. Installation of an add-on card	**21**
12. The pre-installed fans / using the fan control	**21**
13. Installation of additional fans / optimized airflow	**22**

Dear customer!

Congratulations for purchasing this premium quality SHARKOON product.
For a long life time and to take full advantage of this product we recommend you to read this manual completely.

Enjoy our product!
SHARKOON Technologies

1. Features

- ATX case
- 2x 5.25" drive bays (external)
- 1x 5.25" or 3.5" drive bays (external)
- 7x 2.5" or 3.5" bays with removable mounting trays for HDDs (internal)
- Top I/O: 2x USB3.0, 2x USB2.0 and 2x audio, power and reset button, 2x fan speed controllers for up to 6 fans
- 7 slots for add-on cards
- Acrylic side panel
- Plastic front panel with air inlet, drive bay covers in mesh design
- Quick fasteners for optical drives, mainboard mounting with installation opening for CPU coolers
- 4 openings for water cooling
- Cable management system
- Interior painting
- Removable HDD brackets support long VGA cards up to 42 cm

- Fan configuration:

Front panel	2x 120 mm LED fan (pre-installed)
Rear panel	1x 120 mm fan (pre-installed)
Top panel	1x 170 mm fan (pre-installed)

- Dimensions: 510 x 205 x 495 mm (L x W x H)
- Weight: ~9.5 kg

2. Package contents

- ATX case “Tauron”
- Manual flyer
- Accessory kit

Screws for mainboard mounting	Mounting screws for 2.5" HDDs/SSDs	Screws for PSU mounting	Screws for HDD mounting

		Note: If you are missing any of the items listed above, please contact our customer service immediately: support@sharkoon.com (Germany and Europe) support@sharkoon.com.tw (international).
Stand-offs for mainboard	Internal USB3.0 adapter	

3. The case at a glance

Front panel



A – 5.25" drive bays
B – 3.5" mounting bay
C – behind the mesh panel: 2x 120 mm LED fans

Side panel (closed/left)

A – Acrylic side panel

Side panel (opened/left)

A – Mainboard mounting panel
  a – Installation opening for CPU coolers
  b – Cable feedthrough
B – 5.25" drive bays
C – 3.5" mounting bay
D – Quick fasteners
E – HDD cages

Side panel (closed/right)

A – Air inlet for CPU
B – Air inlet for HDDs

Side panel (opened/right)

A – 5.25" drive bays
B – 3.5" mounting bay
C – Quick fasteners
D – HDD cages
E – Mainboard mounting panel
  a – Installation opening for CPU coolers
  b – Cable feedthrough

Rear panel



A – Opening for I/O shield
B – Openings for water cooling
C – 120 mm fan
D – Slot bezels
E – PSU bracket

Top panel



A – On/off button

B – Top I/O:
- a – 2x USB3.0
- b – 2x audio
- c – Reset button
- d – 2x USB2.0
- e – 2x fan control

C – under the mesh bezel:
170 mm fan

Bottom panel

A – Case feet
B – Air inlet for PSU
C – Fan bracket for 120 mm or 140 mm fan

The internal I/O connectors



A – Audio connectors for:
  a – HD Audio
  b – AC'97
B – USB2.0 connector
C – 2x USB3.0 connectors
D – Fan control connector
E – Front-I/O power connector
F – Connectors for:
  a – Power Switch
  b – Power LED –
  c – Power-LED +
  d – HDD-LED
  e – Reset-Switch

4. Installation notes

1. For further information on how to install the PC components, please also refer to their respective instructions.

2. In order to guarantee full functionality of the fan controls and the front connectors, the front-I/O power connector must be connected to the power supply.

5. Rearranging the HDD cages

The HDD cages of the case may be re-arranged, so that VGA cards up to 42 cm can be installed.

Delivery status

Removed HDD cages

Alternative HDD cage arrangements

In order to remove the HDD cages, proceed as follows:

1. Unscrew the thumb screws on the back side of the case and remove both side panels.
2. Lift the attachment lever of the respective HDD cage (fig. 1) and drag the cage out of its fitting (fig. 1b).



fig. 1a

fig. 1b

3. Slide the HDD cage into the respective bottom fitting of the case until the attachment lever locks (fig. 2a and b).

fig. 2a

fig 2b

8. Installation of a HDD

1. Take a mounting frame from one of the HDD cages (fig. 9).



Fig. 9 Mounting frame

2. Place an HDD into the mounting frame (connectors pointing backwards / fig. 10a and b).

Fig. 10a



Fig. 10b

3. Attach the HDD to the mounting frame from below (fig. 11a and b).



Fig. 11a

Fig. 11b

4. Slide the mounting frame into the HDD cage until it locks (fig. 12).

Fig. 12

5. Connect the HDD to the PSU and the mainboard.

9. Installation of an optical device

1. Remove the case's front panel by gently pulling it towards you (fig. 13).

Fig. 13

2. Dismantle the 5.25" front bezel from the mounting bay by removing it from the front panel (fig. 14).

Fig. 14

3. Place the front panel back onto the case.
4. Slide the optical drive into the case's drive bay (fig. 15).

Fig. 15

5. Attach the optical device to the case from both sides using the quick fasteners (fig. 16).



Fig. 16

Note:
If you intend to transport the case, we recommend that you screw-in the built-in devices (additionally).

6. Connect the optical drive to the power supply and the mainboard.

10. Installation of a 3.5" device

1. Remove the case's front panel by gently pulling it towards you.
2. Dismantle the 3.5" front bezel by removing it from the front panel (fig. 17).

Fig. 17

3. Unlock the quick fasteners, which attach the mounting frame for 3.5" devices inside the case (fig. 18a) and remove the mounting frame from the case (fig. 18b).



Fig. 18a

Fig. 18b

(Carefully remove an optionally present metal bezel covering the 3.5" drive bay by using a gripper.)

4. Place the 3.5" device into the mounting frame for 3.5" devices and attach the device to the frame from both sides (fig. 19).



Fig. 19

5. Slide the mounting frame with the installed 3.5" device into the case's mounting bay (fig. 20a) and lock it from both sides using the quick fasteners (fig. 20b).

Fig. 20a



Fig. 20b

6. Connect the 3.5" device to the power supply and the mainboard.

7. Replace the front bezel to the case.

11. Installation of an add-on card

1. Remove the anchor screw of the slot bezel and take it from the case.

2. Insert the add-on card into the respective slot of the mainboard and attach it to the case using the anchor screw (fig. 21).

Fig. 21

3. Close the case.

12. The pre-installed fans / using the fan control

The pre-installed fans provide a 3-pin as well as a 4-pin power connector:



A – 3-pin power connector
B – 4-pin power connector

The 3-pin power connector lets you connect the respective fan to a matching power connector of the mainboard (in this case, the fan will be controlled by the mainboard) or a connector of the case's fan control; in this case the fan speed can be adjusted by using the sliders of the fan controller.

Fan connector of the fan control

Sliders of the fan control

13. Installation of an additional bottom panel fan / optimized airflow

The case provides the opportunity to install an additional 120 or 140 mm fan into the bottom panel. Therefore proceed as follows:

1. Remove the bottom fitting for the HDD cages by loosening its four mounting screws und removing the fitting from the case (fig. 23).

Fig. 23

2. Place the fan against the respective bracket from the inside of the case.

3. Screw the fan to the attachment from the outside.

4. Connect the fan to the mainboard or the PSU.

Notes:
When installing fans, make sure that (cool) air is taken in on the front/bottom of the case and blown out on its rear side/top. The PC components with the highest heat development should be placed directly within the airflow.

Legal disclaimer:

As a continuing policy of product improvement at SHARKOON, the design and specifications are subject to change without prior notice. National product specifications may vary.

All rights reserved especially (also in extracts) for translation, reprinting, reproduction by copying or other technical means. Infringements will lead to compensation.

All rights reserved especially in case of assignation of patent or utility patent. Means of delivery and technical modifications reserved.

Disposal of your old product
Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2002/96/EC.
Please be informed about the local separate collection system for electrical and electronic products.
Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences to the environment and human health.

© SHARKOON Technologies 2011
www.sharkoon.com